

AromaOne™ Air Freshener Dispenser Instructions



- · Use provided key to open dispenser cover as shown above.
- Nesting refill tray includes drip guard and air reducer.
- Choose a location, typically, in rooms with 8' ceilings, mount dispenser 5"-6" from ceiling. For higher ceilings, mount dispensers approximately 7 1/2' from the floor (measured to top of dispenser).

SPECIAL SLIDE-N-LOCK HIDDEN SCREW MOUNTING FEATURE

- FIGURE 1. Remove fan blades by pulling fan blades straight down.
- FIGURE 2. Removal of fan blades exposes BATTERY UNIT RELEASE TABS under battery unit.
- Push on BATTERY UNIT RELEASE TABS while pulling down on battery unit releasing battery unit.
- FIGURE 3. Removal of BATTERY UNIT exposes HIDDEN SCREW MOUNTING.



TO REPLACE BATTERY ASSEMBLY


Position top of assembly below locking rails. Firmly push upwards into **locking** position.

MOUNTING DISPENSERS TO THE WALL

- Avoid mounting Air-Scent® AromaOne™ Freshener Dispenser above urinals to resist vandalism; also avoid mounting units above doors.
- Position dispenser on wall in desired location. Being sure dispenser is plumb and level, mark wall through holes in dispenser with pencil.
 Note: Use uppermost hole and leveling slot.
- Drill 3/16", 15/64" or 1/4" holes into wall at your marks (Hole size is determined by type of wall anchor; see template on reverse side).
- Slide battery assembly downward to expose hidden screw mounting hole described in FIGURES 1, 2 & 3.
- Insert #6x1 countersunk mounting screw into hidden screw mounting hole #1 of backplate assembly. Level backplate and mark hole #2.
 Insert anchor into wall and screw backplate into anchor until tight.
- Replace battery assembly to original position.

BATTERY SERVICE INSTRUCTIONS

- One QUALITY GENERAL PURPOSE Carbonzinc battery is required for 30 days performance. (Do not allow battery to remain over 32 days.)
- One HEAVY DUTY carbon-zinc battery ensures 30 days performance and may last up to 45 days. (Do not allow battery to remain over 60 days).



 One ALKALINE battery should last 60 days. Always dispose of old batteries properly. Note: As battery ages the fragrance intensity reduces drastically.

AROMAONE SMART VERSION ONLY





Three Smart-Swith Settings: Continuous, 60-day and linear output for the best possible end user experience

- Continuous Fan Operations Setting 1-Fan runs full time
- 2) 60 Day Refill Setting

Setting 2-Fan runs 1 minute on, 1 minute off

3) Phases for Consistence Performance Setting 3-Days 1-7 Fan runs 1 minute, stops 3 minutes

Days 8-14 Fan runs 1 minute, stops 2 minutes Days 15-21 Fan runs 1 minute, stops 1 minute Days 22-30 Fan runs continuously


Days 22-30 Fan runs continuously

Always dispose of old batteries properly.

© 2019 ASI

MOUNTING TEMPLATE FOR AROMAONE AIR FRESHENER DISPENSER

Recommended Screw Style: 1-1/4" counter -sink screw Phillips or flathead screw.



METAL PANELS

Use scratch-awl to mark two holes, drill two holes into metal panel and install to panel with screws provided.*

 HOLLOW WALLS (Dry Wall, Plaster)

Drill two holes to accommodate the molly or toggle bolts (insert first) and install dispenser to wall.

With carbine bit, carefully drill two 3/16" holes approximately one inch deep and insert plastic (pencil tip) anchors (#8-10) into holes. Install dispenser to wall with (#8-1") screws provided.*

(Concrete, Block, Brick, Tile)

SOLID WALLS

PANELED WALLS (Wood)
 Locate stud and use scratchawl to mark holes and install dispenser to wall with screws provided (use molly or toggle bolts if unable to locate stud).*





213-1152